

Starting Parlour

- Have rotary program open on the computer in the dairy office

Wet plant room

- Press F3 on Auto Washer
- *PUMP ACTIVE* with a count-down will display on screen, when *SYSTEM CLEARED* appears on screen open taps at the bottom of the milk filter and let water drain out.
- CLOSE TAPS
- Open filter housing cap – Install clean, rinsed filter & make sure filter is right side out
- Close filter housing cap & tighten – make sure filter hosing taps on side not in use are closed
- Take dump-line from wash position and put down drain


Bulk tank room

- Remove milk line pipe from wash position, with pipe on ground pull one-way valve and let water drain out.
- Connect milk pipe to the front of the bulk tank
- Open valve on front of tank by pulling level out and then turning anti-clockwise

Milking parlour

- Unscrew the wash pipe from the side of the milking parlour and hang on bracket on wall-pipe must be placed so pivot bar covers sensor or parlour will not revolve
- Screw on the cap to side of the parlour when pipe is removed

Wet plant room:

- Use  arrows on Auto Plant Washer to select “ready to milk” then press green button to start
- TURN ON PLATE COOLER

Milking Parlour

- Turn off automatic parking on Swift flow Revolver Control Console
- Close auto entry saloon gates
- Press and hold platform reverse button, to reverse platform 3-4 units
- Press platform forward button to move platform forward until the display shows a countdown and machine calls “all systems ready”
- Stop the parlour with unit 1 in line with cow entry
- On commander unit box screen press F100 and then enter
- All clusters will lift
- Close jetter lids, wet down parlour and turn on cluster spray tap
- **Ready to milk**
- **Check bulk tank room and wet room after approximately 30 cows have entered platform to ensure all is operating correctly.**

Closing down the Parlour

Milking Parlour

- Wash and rinse all the units as the cows are coming off the parlour
- When all cows have left the parlour, turn off the cluster spray tap walk around the platform washing down the screens/clusters/bars etc.
- When the whole platform is rinsed, return to milking station and wash all clusters
- On Commander unit box screen press F103 and enter.
- Release the clusters using soft start or button and place in jettors
- Wash all screens
- Wash all dirt from the retention bars
- One final rinse of the platform
- Turn on automatic parking on Swiftflow Revolver Control Console, press platform forward button and let the parlour park itself
- Close auto entry gates, drop scraper to cleaning position on backing gate- switch on side of Swiftflow Revolver Control Console.
- Press scraper reverse button to scrape collecting yard

Wet Plant Room

- Press F3 on Auto Plant Washer to clear the system
- **TURN OFF PLATE COOLER**


Bulk Tank Room

- Close valve on front of tank by pulling lever out and turning clockwise
- Remove milk pipe from the tank and attach it to the wash position
- Rinse away any spilt milk and put wash cap on front of tank

Milking Parlour

- Unscrew the cap from side of the parlour
- Screw on wash pipe to the side of the milking parlour

Wet Plant room

- Press the red button on Auto Plant Washer to close down parlour
- Use  arrows on Auto Plant Washer to select hot wash/acid wash press enter
- See chart in dairy re daily wash selection
- **Parlour shut down**