

Guardian Supreme Plant Washer.

Users Chart.

To Go Milking.

When SwingArm is Put in Bulk Tank. Or Bottom Fill.

(WAITING MILKING must be up on Display.)



Press Orange Centre Botton.(Vac pump will Start)

*** MILKING *** will show up on Display.

To Go Washing.

When SwingArm is put in Wash Position.(Vac Pump will Stop)

(WAITING WASH or WAITING SANIT.must be up on Display)



Press Orange Centre Button.(Water will Start Filling)



(F on Display means Water FILLING.)

Vac Pump will START when Wash Trough is Full.

Vac Pump will Start & Stop Between Cycles.



Guardian Supreme Plant Washer.

Changing Between Washes.

CHANGING FROM DETERGENT TO ACID.

WAITING WASH MUST BE UP ON DISPLAY.



Press & Hold  for 4 sec.

This allows you change Between Detergent & Acid Washes.

CHANGING FROM WASH TO SANITIZER.

(If Washer is Programed for Sanitizer wash)

WAITING WASH MUST BE UP ON DISPLAY.



Press & Hold  for 6 sec.

This allows you change Between WAITING WASH & WAITING SANIT.



Change Chemical Pipes in Chemical Pumps Annually.