























User Instruction Chart

MTC III Control

Empty the tank by tanker collection		
1	Press 	Pilot light  is flashing and display alternately shows temperature and "OFF"
2	Take a sample of the milk as soon as pilot light  is off	
3	Remove the cover from the milk outlet and attach the hose	
4	Open the outlet valve and empty the tank	
5	Disconnect the hose and replace the cover on the milk outlet	
6	Press  to start the tank cleaning cycle	Pilot light  is on
Cleaning		
1	Check that a sufficient amount of detergent is available	
2	Check that the outlet valve is in the "open" position	
3	Check that the cover has been placed on the outlet	
4	Check that the manhole is closed	
5	Press  to start the tank cleaning cycle	A fault has occurred if pilot light  is flashing. Remedy the fault and restart the tank cleaning process
		The tank cleaning has finished if the pilot light  comes on
6	After the cleaning process, manually clean the manhole cover, ring and edge with a solution of warm water and a cleaning agent	
7	Regularly check that the spray pipe and the spray balls are not blocked	
Extra rinsing cycle / disinfection rinse		
1	Simultaneously press  and  to start the extra rinsing cycle	A fault has occurred if the light  is flashing. Remedy the fault and restart the rinsing cycle
		The rinsing cycle has finished if the  light comes on
2	Add a disinfectant during the water filling process, if so required	
Priming a dosing pump		
1	Simultaneously press  and  to prime dosing pump no. 1	
2	Simultaneously press  and  to prime dosing pump no. 2	
Cooling		
First milking:		
1	Check that the tank is thoroughly clean and close the outlet valve	
2	Press  to start the cooling programme	Pilot light  is on
3	Fill the tank with milk	
4	Immediately after milking: check the milk temperature	
Next milkings:		
1	Press  to speed up the start of the cooling programme	Pilot lights  and  are on; the LED in the bottom right corner of the display is flashing
2	Fill the tank with milk	
3	Immediately after milking: check the milk temperature	
General		
1	Regularly check the milk temperature	
2	Never press  if cooling is not required	
3	Put this instruction card in the immediate vicinity of the tank	

Safety	
Emergency stop: turn the main switch on the switch box into the "0" position	
Refrigerant type:	Mueller dealer:
Charge: _____ kgs	